

# **HAFFMANS** AuCoMet-i IN-LINE CO, METER

PRODUCT LEAFLET



### **GENERAL PRODUCT INFORMATION**

In the beer and beverage industries, the content of dissolved carbon dioxide  $(CO_2)$  and dissolved oxygen  $(O_2)$  are of utmost importance to the quality, taste and flavor stability of beer and carbonated beverages. Particularly,  $O_2$  is becoming an increasingly important parameter, as excess  $O_2$  can compromise the flavor stability and lead to significantly reduced product shelf life.

Because of this, breweries and soft drink manufacturers continuously seek to control and measure the concentrations of  $\rm CO_2$  and  $\rm O_2$  during production.

The In-line  $CO_2$  Meter, type AuCoMet-i, sets standards in terms of quality, handling and ease of maintenance. It enables a fast and accurate determination of the  $CO_2$ content in beer and beverages based on the internationally standardized method of Henry's Law. In addition, the AuCoMet-i can easily be extended with an  $O_2$  sensor. Pentair Haffmans' optical  $O_2$  measurement technology provides better response times than traditional  $O_2$  measurement instruments, and does not require frequent calibration. With the AuCoMet-i both,  $CO_2$  and  $O_2$  measurements, can be done independently.

The AuCoMet-i is supplied with a separate control unit that can be field or panel mounted. This offers the operator maximum flexibility to position the control unit at a location that allows optimal access to both the operating panel and the display. One  $CO_2$  sensor and one  $O_2$  sensor can be connected to each control unit.

The  $\text{CO}_2$  sensor and  $\text{O}_2$  sensor are hygienically designed according to the EHEDG guidelines. The AuCoMet-i is easily mounted in an in-line housing with Varivent<sup>®</sup> connections.

# BENEFITS

#### Cost saving

- efficient production process operation the need for minimal preventive
- maintenance reduces OPEX by more than 50%
- robust and modular design

# APPLICATIONS

- In-line, at critical locations in the production line where the determination of the dissolved CO<sub>2</sub> and O<sub>2</sub> content (optional) is required and adjustments can be made, typically after filtration, carbonation and/or blending and before filling.
- In combination with a Pentair Haffmans' CO<sub>2</sub> dosing unit, type CCR, to determine the CO<sub>2</sub> quantity and immediately adjust the CO<sub>2</sub> dosing rate if necessary.

# **HAFFMANS** AuCoMet-i IN-LINE CO, METER

PRODUCT LEAFLET

# **TECHNICAL DATA**

#### CO, CONTENT

Measuring range 2.0-10.0 g/l

**Accuracy** ± 0.10 g/l

Measuring units g/l, % b.w., Vol, kPa

Measuring interval approx. 30 sec.

#### 02 CONTENT (OPTIONAL)

Measuring range 0.0-2,000 ppb

Accuracy ± 1 ppb + 2 % of m.v. (at 20 °C)

**Measuring units** ppb, μg/l, ppm, mg/l, % a.s.

Measuring interval 30 sec. (adjustable from 2 - 999 sec.)

- 100

O<sub>2</sub> sensor (optional)



# HAFFMANS BV

P.O. BOX 3150 NL-5902 RD VENLO, NETHERLANDS WWW.HAFFMANS.NL

**Temperature** -5.0 - 40.0 °C, acc. ± 0.1 °C

**Pressure** 0.0 - 10.0 bar, acc. ± 0.01 bar

Memory capacity Up to 500 measurements

Process temperature Max. 110 °C

**Process pressure** Max. 10 bar

**Power supply** 85-264 VAC wide range (optional 24 VDC)

**Dimensions CO<sub>2</sub> analyzer** 320 x 160 x 320 (LxWxH mm)

**Dimensions O<sub>2</sub> sensor** 200 x 100 (LxD mm)

**Connection** Varivent®

Protection class

# SCOPE OF SUPPLY

- Control unit with wall mounting bracket
- Set of I/O cables
- CO<sub>2</sub> sensor
- Software set
- Mains cable
- Service set
- Sensor communication cable
- Instruction manual

### OPTIONS

- Certificate of measurement
- Extended I/O (for feedback signals)
- Profibus DP
- Pressure calibration set
- Control unit mounting set (for pipes DN 40-DN 125)
- In-line housing with two Varivent<sup>®</sup> connections, inspection glasses and clamps (pipe dimensions to be specified at time of enquiry)
- O<sub>2</sub> sensor, type Vari/LHO, with O<sub>2</sub> sensor communication cable and calibration beaker assembly
- 0<sub>2</sub> calibration set



All Pentair trademarks and logos are owned by Pentair, Inc. All other brand or product names are trademarks or registered marks of their respective owners. Because we are continuously improving our products and services, Pentair reserves the right to change specifications without prior notice. Pentair is an equal opportunity employer.

AuCoMet-i E-4 /12 © 2012 Pentair, Inc. All Rights Reserved.